

VIBRATOR TOYJOY GET REAL GOLD DICKER

User manual



CONTROL

- 1) Unscrew the cap, insert the batteries according to the poles and screw the cap on.
- 2) Short press the button on the base to turn on the first mode by vibrating it and repeated presses of the button to change the individual rhythms.
- 3) To switch off, hold the button for 3 seconds.

MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrator is water resistant, so maintenance is very easy. Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!** You could only immerse the product in water if it was **waterproof**.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The vibrator is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vibrator.