

# User manual

## CONTROL

GRAN

1) Turn the vibrator on/off by holding the middle power button for 3 seconds.
2) Use the arrow buttons and short presses to change the vibration mode.

### MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The vibrator is **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play.

### LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and it could become sticky.

### **DRIVE AND CHARGING**

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. **STORAGE** 

Store separately from other erotic aids in a dry and dark place.

#### **PACKAGING CONTENTS**

In the package you will find a vibrator and USB cable for charging.



## Trinet Corp., s.r.o.

Provozní 5560/1b 722 00 Ostrava – Třebovice, Czech Republic

#### Potřebujete poradit?

Napište nám na flagranti@flagranti.cz nebo zavolejte na tel.: +420 774 082 678