 **ENGLISH / USER MANUAL**

**BEFORE USE** - CHARGE THE BUTT PLUG COMPLETELY BEFORE FIRST USE WITH THE INCLUDED USB CABLE. CONNECT THE MAGNETIC END OF THE CHARGING CABLE TO THE METAL CONNECTION POINTS AT THE BASE OF THE BUTT PLUG. CONNECT THE CABLE TO A USB PORT. WHEN THE BATTERY IS CHARGING, THE LED LIGHT BLINKS. WHEN THE LIGHT STOPS BLINKING AND BURNS CONSTANTLY, THE BATTERY IS COMPLETELY CHARGED. OPEN THE BATTERY COMPARTMENT OF THE REMOTE CONTROL AND REMOVE THE PROTECTIVE PLASTIC PLACED UNDER THE BATTERY. CLOSE THE BATTERY COMPARTMENT.

**TURNING ON AND OFF** - HOLD THE POWER BUTTON ON THE BUTT PLUG FOR 3 SECONDS UNTIL THE LED LIGHT TURNS ON. THE BUTT PLUG IS NOW IN STAND-BY MODE. IF THE LIGHT DOESN'T TURN ON, THE BATTERY IS EMPTY. CHARGE THE BATTERY FIRST AND THEN TRY AGAIN. HOLD THE POWER BUTTON ON THE REMOTE CONTROL FOR 3 SECONDS. THE BUTT PLUG WILL START ROTATING. IF THIS IS NOT THE CASE, THE BATTERY IS EMPTY OR NOT PLACED CORRECTLY. CHECK THE BATTERY IN THE REMOTE CONTROL AND REPLACE IT IF NECESSARY. AFTER USE, HOLD THE POWER BUTTON ON THE REMOTE CONTROL FOR 3 SECONDS TO TURN OFF THE ROTATIONS. HOLD THE POWER BUTTON ON THE BUTT PLUG FOR 3 SECONDS UNTIL THE LED LIGHT TURNS OFF.

**OPERATING** - THE VARIOUS ROTATION PATTERNS AND SPEEDS CAN BE CONTROLLED WITH THE REMOTE CONTROL. PRESS THE + BUTTON TO GO TO THE NEXT SETTING. PRESS THE - BUTTON TO GO BACK TO THE PREVIOUS SETTING. THERE ARE 4 ROTATION SPEEDS AND 6 ROTATION PATTERNS IN TOTAL. THE ROTATIONS CAN ALSO BE CONTROLLED WITHOUT THE REMOTE CONTROL. IN THAT CASE, PRESS THE POWER BUTTON ON THE BUTT PLUG TO GO TO THE NEXT ROTATION SETTING.

**LUBRICANT** - THE BUTT PLUG IS MADE OF SILICONE AND CAN THEREFORE ONLY BE USED IN COMBINATION WITH WATER-BASED LUBRICANT. OTHER LUBRICANTS CAN NEGATIVELY AFFECT THE MATERIAL, ALLOWING BACTERIA TO GROW AND MAKING IT IMPOSSIBLE TO HYGIENICALLY CLEAN THE TOY.


**CLEANING** - RINSE THE BUTT PLUG WITH LUKEWARM WATER. APPLY TOY CLEANER TO THE BUTT PLUG AND RINSE IT OFF WITH LUKEWARM WATER AGAIN. REPEAT THIS STEP IF NECESSARY. LAY THE BUTT PLUG DOWN TO DRY OR DAB IT DRY WITH A CLEAN AND LINT-FREE CLOTH OR TOWEL.

**STORAGE** - SAFELY STORE THE BUTT PLUG AT A DRY AND DARK PLACE. USE A TOY BAG TO PROTECT THE TOY FROM DUST AND SCRATCHES.


THIS PRODUCT IS SOLD AS A NOVELTY PRODUCT ONLY. ALL RIGHTS RESERVED. TO AVOID INJURY OR AGGRAVATION OF PRE-EXISTING CONDITIONS THIS PRODUCT SHOULD NOT BE USED ON BRUISED, SWOLLEN OR INFLAMED AREAS. ONLY USE THIS PRODUCT AS INSTRUCTED. NO MEDICAL CLAIMS ARE WARRANTED OR IMPLIED BY THE USE OF THIS PRODUCT. ITS USE IS AT YOUR OWN RISK. DO NOT ATTEMPT TO WARM THIS PRODUCT IN A MICROWAVE OR CONVENTIONAL OVEN. WASH BEFORE AND AFTER USE. WITH A MILD SOAP AND WARM WATER. ALLOW TO DRY COMPLETELY BEFORE STORING SEPARATELY FROM OTHER TOYS IN A COOL, DRY PLACE. STORE AT ROOM TEMPERATURE. WE RECOMMEND USING A WATER-BASED LUBRICANT WITH YOUR PRODUCT. PLEASE DO NOT USE PERFUMED OR ALCOHOL-BASED LUBE GELS OR MASSAGE OILS TO AVOID DAMAGE. WE DO NOT RECOMMEND SILICONE-BASED LUBRICANTS OR GELS.

## HOW TO USE | EQUIPMENT

1. LUBRICATE FIRST




2. HOW TO RECHARGE



  
MAGNETIC CHARGING POINT

## ASTEROID | REMOTE-CONTROLLED RIMMING ANAL PLUG



### EQUIPMENT SPECIFICATIONS

**DIMENSIONS VIBRATOR** / 139\*70\*45 MM | 5.5\*2.8\*1.8 INCH  
**DIMENSIONS REMOTE** / 81\*34\*22 MM | 2.4\*1.3\*0.9 INCH  
**INSERTABLE LENGTH** / 110 MM | 4.3 INCH  
**MAXIMUM DIAMETER** / 45 MM | 1.8 INCH  
**MASS / TOY:** 173 G | 6.10 OZ // **REMOTE:** 15 G | 0.5 OZ  
**SETTINGS** / 4 ROTATION SPEEDS, 6 PATTERNS  
**REMOTE CONTROL RANGE** / 8 M | 26 FT  
**WATER RESISTANCE / TOY:** IPX8 | **REMOTE:** IPX4  
**POWER / TOY:** LI-ION, 300 MAH, 3.7V | **REMOTE:** CR2032 (1PC)  
**MAX. CHARGING CURRENT** / 350 MA  
**CHARGING VOLTAGE** / 5.0 V  
**CHARGING TIME** / APPROX. 55 MINUTES  
**OPERATING TIME** / APPROX. 45 MINUTES  
**STANDBY TIME** / UP TO 6 MONTHS  
**MAX. NOISE LEVEL** / <66 DB  
**MATERIALS** / ABS, SILICONE

