VIBRATOR YEQU KIERAN E-SHOCK

User manual

CONTROL
1) Hold the bottom button with the wave symbol for 2 seconds to turn on and off.
2) Subsequent short button presses change the vibration and pulsation modes.
3) Hold the top button with the lightning bolt symbol to turn the electrical stimulation on and off.
4) Short presses change the pulse rhythms. Both functions can be controlled independently.

MAINTENANCE
After each use, rinse the vibrator with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF
The vibrator is **water resistant**, so maintenance is very easy.
The vibrator can be splashed with water, but you **MUST NOT immerse it in water!**
Waterproof means that you could completely submerge the product in water and enjoy water play.
Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
In the package you will find a vibrator and USB cable for charging.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169