


# 10

VIBRATING PATTERNS

ONE TOUCH ON/OFF BUTTON  
WHICH DELIVERS 10 DIFFERENT  
VIBRATING PATTERNS



## RECHARGEABLE SUPER ROTARY VIBRATOR

### Warnings and Disclaimers:

- To recharge the vibrator, please only use the USB cable that we have provided in the packaging
- This product is intended for use when supplied with power from the designated battery or power supply unit. Other usage may be dangerous and will invalidate any approval given to this product.
- Please recharge the device for 3 hours before initial usage.
- Do not short the terminals. Connection to improper grounded equipment can result in short-circuit.
- Use of non-original manufacturer-approved accessories will damage the product and cause explosion.
- Recharge the product at room temperature.
- Store in a cool and dry place.
- If terminals are soiled, clean with a soft cloth.
- Unplug from the socket when the device is not being recharged.
- Do not expose to fire, water or moisture
- Keep the device away from fire.
- Keep the device out of reach of infants or children.
- Do not expose the device to any mechanical shock.

### Safety Precautions:

#### Device will get warm after prolonged use

- The product will get warm after being used for a period of time
- It is highly recommended to turn the product off and let it cool down before using it again.
- The product should be placed away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

### Main Composition: ABS Plastic, Silicone

**Caution:** This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of skin lacerations. Prolonged and frequent use are not advised or recommended as this product is sold as novelty purpose only. This product should be used with discretion. No medical claims are warranted or implied by the use of this product. This product cannot provide water resistance in the bath or in the pool. Splash resistance can be provided only in the shower or during cleaning.

### Technical Data:

**Operating temperature:** 4°C - 60°C  
**Charging voltage:** 5V  
**Battery:** Li-Ion 3.7V 0.999Wh  
**Battery capacity:** 270mAh  
**Charging:** Approx. 3 hours  
**Charging cycles:** 500  
**Usage period:** Approx. 60mins  
**Interface:** USB port (5V >1A)

### How To Use Your Vibrator:



- Hold for few seconds to switch on the device
- Press to change the patterns. When the device is on
- Hold for few seconds to switch off the device

### Charging Instructions:



Align and plug in the 2.5mm pin into the device

*\*Ensure the 2.5mm pin is plugged into the charging point perpendicularly.*

*\*Plugging the cable incorrectly will cause damage to the device.*



Plug the USB cable into the power sources with appropriate adaptor or USB port from computer



USB PLUG  
(Not included)  
(Output: 5V=1A)



PORTABLE BATTERY  
(Not included)  
(Output: 5V=1A)




POWER ADAPTOR  
(Not included)  
(Output: 5V=1A)



PC/MAC  
(Not included)  
(Output: 5V=1A)



CAR ADAPTOR  
(Not included)  
(Output: 5V=1A)



LED light

- The LED light starts blinking when the device is being recharged.
- The LED light keeps steady when the device is fully recharged.



Unplug the USB cable from the device after fully recharged.

### Warning:



The pin could be damaged with overexertion.



Please do not shake the pin when it is plugged into the device



IJ00673E

EN

EN