dreamtoys

EXPLORE · DISCOVER · ENJOY



GODDESS COLLECTION

EN

To turn on: Press and hold the diamond button (1) for 2 seconds, the unit is in stand-by mode.

Then short press the upper button (2) to cycle through shaft vibrations + thrusting modes.

Press and hold the upper button (2) for 2 seconds to stop the shaft vibration + thrusting.

Short press the lower button (3) to cycle through the clitoral rabbit vibration modes.

Press and hold the lower button (3) for 2 seconds to stop the clitoral rabbit vibrations.

To turn off: In any mode, press and hold the diamond button (1) for 2 seconds.

To charge: click the magnetic USB-connector gently on the magnetic contact points on the device (4).

Caution: This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of the skin. Prolonged and frequent use is not advised or recommended.

Product Material: Silicone + ABS

Noise level: ≤60DB Waterproof Grade: IPX7

TongaBV

Noordpolderstraat 21 4571 LR Axel The Netherlands www.tongabv.com