

PIPEDREAM 3SOME WALL BANGER BEADS BLACK

User manual



CONTROL

- 1) Hold the button on the bottom for 3 seconds to turn on. The beads will start their first vibration and their LED will light up.
- 2) Subsequent short presses change the vibration and pulsation modes.
- 3) Turn them off by long pressing the button again for 3 seconds.
- 4) For use with the remote control, switch the beads to the first vibration mode and short presses on the remote control to change the modes. The remote does not need to be switched on in any way.
- 5) To pause the vibration, hold down the button on the remote control for 3 seconds.
- 6) To start it again, hold the button for 3 seconds. The beads must then be turned off with their own button.

MAINTENANCE

After each use, rinse the beads with lukewarm water and soapy detergent. You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The beads is **water resistant**, so maintenance is very easy. The beads can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The beads is powered by an integrated Li-ion battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. The remote control is powered by CR1620 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find beads, remote control, suction cup attachment, USB charging cable and batteries type CR1620