

# DEPLOYABLE PENIS SEVEN CREATIONS 9" STRAP-ON VIBRATING



## User manual

### CONTROL

- 1) A short press of the button on the vibrator will put it into standby mode. You will know this by its LED flashing.
- 2) Subsequent short button presses will turn on and change the vibration and pulsation modes.
- 3) To turn it off, long press and hold the button for 3 seconds.
- 4) To use the remote control, place the vibrator in standby mode and press the bottom power button on the remote.
- 5) This will turn on the vibration and switch modes using the top button with the ripple symbol.
- 6) To pause the vibration, briefly press the power button again.
- 7) Switch the vibrator completely off again with the button at the bottom.

### MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent. You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The vibrator is **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play.

### LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. The remote control is powered by CR 2032 battery.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a vibrator, remote control, USB cable for charging and a battery type CR 2032.