

# MASTURBATOR FRENCH KISS

## User manual



### CONTROL

- 1) Insert 2 AA batteries into the remote control according to the marked poles.
- 2) Insert the hose leading from the masturbator into the balloon.
- 3) There is a wheel on the side of the remote that turns on the vibrating egg and then rotates it to control the intensity of the vibration.
- 4) Turn it completely off by turning it to the OFF position.
- 5) Squeezing the balloon will create a vacuum and suction sensation.

### MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The masturbator is **not water resistant or waterproof!**

### LUBRICATION

Due to the material of the vibrator, you can use **lubricants of any base**.

### DRIVE AND CHARGING

The controller is powered by two AA batteries. We recommend using alkaline batteries for greater endurance or rechargeable batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

Masturbator with remote control and balloon.