

# VIBRATING EGG VELVET



## User manual

### CONTROL

- 1) Unscrew the cap and insert the batteries according to the poles.
- 2) Short presses on the top button to turn it on and add intensity.
- 3) Short presses of the bottom button reduce the vibration strength again until it turns off.

### MAINTENANCE

After each use, rinse the egg with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The egg is **water resistant**, so maintenance is very easy.

Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!**

You could only immerse the product in water if it was **waterproof**.

### LUBRICATION

Due to the material of the vibrator, you can use **lubricants of any base**.

### DRIVE AND CHARGING

The egg is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

Vibrating egg with remote control.