

# Customer Information

Dear customer,

**Congratulations on the purchase of your vibro sex toy. A good choice! This high-quality product can be used as a massage and stimulation device during foreplay, for masturbation or as an additional aid during intercourse. With this customer information we would like to give you useful advice and tips on how to use this quality product. This information was put together so that you can get the utmost enjoyment out of your vibro sex toy and its many possible uses. Please keep the customer information safe.**

## Instructions for the use of the batteries:

1. Please refer to the information on the package, to see whether the device is delivered with or without batteries, and how many are needed for operation.
2. Please find your type of device among the following drawings and follow the instructions to insert the batteries. **(Abb. 1 – 21)**
3. Make sure the battery contacts are clean and shiny to ensure a firm contact with the batteries.
4. Do not short out the contacts, i.e. do not bridge the contact points with metallic objects.
5. Make sure the batteries are placed firmly and correctly in the battery compartment (+ and -).
6. Use only new or newly charged batteries. Do not combine old and new batteries for operation.
7. **Remove the batteries from the device after using the vibro sex toy in order to prolong the life of the batteries and avoid corrosion that can develop inside the battery unit due to moisture.**

## Instructions for the use and maintenance of the vibro sex toy

1. Clean the vibro sex toy before the first and after every further use with warm water and soap. Caution – keep in mind that this is an electrical device and that moisture in the battery compartment can cause a defect. After every anal use, the device should be thoroughly cleaned before a further vaginal use.
2. Apply a sufficient amount of lubricant to the surface of the vibro sex toy. Make sure not to cover the battery-operated control unit since this can lead to a malfunction of the device. **IMPORTANT:** Only use water-soluble lubricants! Oil-based lubricants corrode the material.
3. After gentle insertion or placement of the device, carefully push or turn the speed control and set the desired vibration speed and/or choose any function from the control unit you desire. Turn, push or slide the speed control slowly and gently, not forcefully.
4. Turn off the vibro sex toy after use and slowly pull it out of or away from your body.
5. Let the vibro sex toy cool off after use before you put it away.
6. Keep your vibro sex toy in a clean, cool and dry place, because moisture can damage the batteries and motor. Keep out of direct sunlight!
7. Keep the vibro sex toy separate and not together with other products made of different materials in order to avoid chemical reactions.

## Warnings and general advice:

1. Keep out of reach of children. Small parts can be swallowed.
2. Do not use the vibro sex toy in places where the skin is diseased, irritated or infected.
3. Do not pass the vibro sex toy on to others in order to avoid diseases and infections.
4. Carefully read the description of materials on the package in order to avoid allergic reactions, e.g. to latex for example.
5. Make sure that the batteries are inserted safely and correctly in the battery compartment. Pay attention to the marking of the poles with + and - and insert the batteries accordingly.
6. In case of non-waterproof vibro sex toys, make sure that the battery or control unit does not get wet.
7. In case of waterproof vibro sex toys, make sure the battery compartment is firmly closed after insertion of the batteries.
8. Should the vibro sex toy overheat, turn it off immediately and let it cool off before renewed use.
9. Do not try to charge non-rechargeable batteries.
10. Do not throw onto a fire.
11. Careful handling and use of the vibro sex toy protects you from damages and accidents.
12. Do not heat or cool the product a lot, except where expressly recommended to do so.
13. Do not excessively bend or stretch the vibro sex toy. Never use any force.
14. Use the vibro sex toy exclusively as a massage and stimulation device during foreplay, for masturbation or as an additional aid during intercourse, and not for any other purpose.
15. The supplier is not liable for the improper use of the product.
16. The product is not intended for commercial use.

## Note regarding the environment:

Please do not throw away the packaging material, but recycle it instead. Please take old devices to your relevant collection points in accordance with your national legislation and the directives 2002/96/EC and 2006/66/EC. The sign of a dustbin with a line through it on bikes (♻️) means that this product must be disposed of at a collection point for waste electrical equipment, in order to achieve the best possible reuse of raw materials by recycling.

## Battery return

Batteries do not belong in household waste. As a consumer, you are legally obliged to return used batteries. You can take your old batteries to your local public collection points, or anywhere where batteries are sold. You can also return such batteries to us for free. Batteries containing hazardous substances are labelled with the sign ♻️ and one of the chemical symbols Cd (= battery contains cadmium), Hg (= battery contains mercury) or Pb (= battery contains lead). Lithium batteries and accu packs of all systems may only be returned in the discharged state to the disposal points. To protect against short circuits when batteries are not fully discharged, the battery poles for these product types may need to be isolated with adhesive tape before returning.

(Abb. 1 – 21)

