

# REBEL HEATING MASTURBATOR



## User manual

### CONTROL

- 1) Hold the bottom button with the wave symbol for 2 seconds to turn on. The vibrator will greet you by lighting up the LED and starting its first vibration.
- 2) Subsequent short button presses change the vibration and pulsation modes.
- 3) Turn it off by holding the power button long again for 2 seconds.
- 4) Hold the top button with the flame symbol for 2 seconds to switch the heating on or off.
- 5) Both functions can be used independently.

### MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The masturbator is **water resistant**, so maintenance is very easy. The masturbator can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

### LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The masturbator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a masturbator and magnetic USB cable for charging.