

YOU2TOYS COUPLES TOY 9 PIECES SET (Vibrator and vibrator with clitoral stimulator)



User manual

VIBRATOR CONTROL

- 1) The bottom of the vibrator serves as a cover for the batteries.
- 2) Remove the battery cover, insert the AA battery (not included) and screw the cover back on.
- 3) Turn on the vibrator by pressing the button on the battery cover.
- 4) Subsequent short presses to switch between the different vibration rhythms.
- 5) Turn the vibrator off by holding the button for approximately 3 seconds.

VIBRATOR CONTROL WITH CLITORAL STIMULATOR

- 1) The bottom of the vibrator serves as a cover for the batteries.
- 2) Remove the battery cover, insert 2 AAA batteries (not included) and screw the cover back on.
- 3) Turn the vibrator on by sliding the switch on the battery cover to the "ON" position.
- 4) Turn it off by sliding the switch on the battery cover to the "OFF" position.

MAINTENANCE

After each use, rinse the products with lukewarm water and soapy detergent.

You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

Vibrators are not waterproof or water resistant!

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The vibrator is powered by an AA battery and the clitoral stimulator vibrator is powered by two AAA batteries. We recommend the use of alkaline or rechargeable batteries for greater endurance.

STORAGE

Store separately from other erotic aids in a dry and dark place.