

# VIBRATING EGG YEQU REMOTE CONTROL



## User manual

### CONTROL

- 1) The control of the egg is by remote control.
- 2) Hold the on/off button on the remote control for about 3 seconds.
- 3) Short presses of the button change the rhythms of the vibration modes.

### MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The egg is **water resistant**, so maintenance is very easy. Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!** You could only immerse the product in water if it was **waterproof**.

### LUBRICATION

Due to the material of the vibrator, you can use **lubricants of any base**.

### DRIVE AND CHARGING

The egg is powered by two AAA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries. The driver is equipped with an internal disposable battery.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

Vibrating egg and remote control.