

Operation Instructions

How to Start:

- 1: Long press W/⏻ for 2s for startup and product starts vibration;
 - 2: Keep pressing it to cycle among 10 vibration modes or strengths;
 - 3: Press ⚙ button for heating. This key is valid for products with heating functions only.
-

How to Charge:

- 1: Ⓞ is waterproof charge hole;
 - 2: Insert the charging cable attached in package into charge hole and device charging is started if indicator lamp at "Power" key flickers;
 - 3: Indicator lamp is normally on after charging completes;
 - 4: Recommended charging period: 3h
-

How to Clean, Store and Keep Safety

Please thoroughly clean this Product using safe and non-irritant water-soluble detergent and wipe the water stains using clean and dry lint.

If this product is to be idled for long time, please put it back in original packaging or storage bag to keep out unnecessary scratch and external bacteria.