

JAMYJOB NOVAX MASTURBATOR

User manual



CONTROL

1) Hold down the top power button for 3 seconds.

The masturbator will light up the button LEDs and start the first vibration.

2) Short presses of this button change the individual vibration and pulsation rhythms.

3) If you want to pause the vibration, press the button twice briefly.

4) Short press the middle button to turn on and change the automatic pocket inflation modes.

5) They will inflate and deflate at different intervals.

6) To quickly deflate the pockets, briefly press the bottom button.

7) The automatic mode will be interrupted and the air will be blown out.

8) If you want to inflate the pads more, hold this bottom button until you reach the desired pressure.

9) To turn the masturbator off, hold the top power button again for 3 seconds.

10) When handling, avoid plugging the two holes in the top back. This is where the device sucks in air. Clogging could damage the motors.

MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent.

You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The masturbator is **water resistant**, so maintenance is very easy.

The masturbator can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The masturbator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a masturbator and USB cable for charging.