



QUICK START GUIDE

SIZE

2.68 in (68 mm)

2.24 in (57 mm)






6.5 in (165 mm)



2.36 in (60 mm)

2.48 in (63 mm)

FUNCTION




- ON/OFF:
Hold on "  " for 3 seconds
Press "  " to switch 9
licking modes



- Press "  " to switch
3 suction modes


HOW TO USE



USB MAGNETIC CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output

*Please make sure your toy is fully charged while the first time



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Please do not use under water or during shower.
- If the product can't be charged when electrified, please wait for 10 mins to confirm.

PRODUCT CLEANING

- Clean Please clean product with warm water or antibacterial soap.
- Wipe Dry the product with clean cloth or towel.
- Store Keep the product in a cool, dry, clean place.
- Attention Never clean this product with organic cleaner containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



MADE IN CHINA