 ENGLISH / USER MANUAL

BEFORE USE - CHARGE THE RING COMPLETELY BEFORE FIRST USE WITH THE INCLUDED USB CABLE. PLUG THE PIN AT THE END OF THE CHARGING CABLE INTO THE CHARGING POINT OF THE RING. CONNECT THE CABLE TO A USB PORT. WHEN THE BATTERY IS CHARGING, THE LED LIGHT FLASHES. WHEN THE LIGHT STOPS FLASHING AND BURNS CONSTANTLY, THE BATTERY IS COMPLETELY CHARGED.

USE - PLACE THE RING AROUND THE BALLS AND THE BASE OF THE PENIS WHEN THE PENIS IS FLACCID. DURING AN ERECTION, THE RING TIGHTENS AROUND THE PENIS AND BALLS AND RESTRICTS THE BLOOD FLOW. THIS PROVIDES A HARDER AND LONG-LASTING ERECTION AND THE PENIS AND BALLS WILL BECOME MORE SENSITIVE.

TURNING ON AND OFF - HOLD THE POWER BUTTON FOR 3 SECONDS TO TURN ON THE TOY. THE LED LIGHT WILL TURN ON. IF THIS IS NOT THE CASE, THE BATTERY IS EMPTY. CHARGE THE BATTERY FIRST AND THEN TRY AGAIN. AFTER USE, HOLD THE BUTTON FOR 3 SECONDS TO TURN OFF THE TOY.

OPERATING - THE DIFFERENT VIBRATION SETTINGS CAN BE CONTROLLED WITH THE POWER BUTTON. PUSH THE BUTTON TO TURN ON THE VIBRATIONS. PRESS THE BUTTON AGAIN TO GO TO THE NEXT SETTING. THERE ARE 3 VIBRATION SPEEDS AND 7 VIBRATION PATTERNS IN TOTAL. AFTER THE LAST SETTING, THE VIBRATIONS START AGAIN AT THE BEGINNING.

LUBRICANT - THE RING IS MADE OF SILICONE, THEREFORE THE RING CAN ONLY BE USED IN COMBINATION WITH WATER-BASED LUBRICANT. OTHER LUBRICANTS CAN NEGATIVELY AFFECT THE MATERIAL, ALLOWING BACTERIA TO GROW AND MAKING IT IMPOSSIBLE TO HYGIENICALLY CLEAN THE TOY.

CLEANING - RINSE THE RING WITH LUKEWARM WATER. APPLY TOY CLEANER TO THE RING AND THOROUGHLY RUB IT CLEAN. REPEAT THIS STEP IF NECESSARY. RINSE THE RING WITH LUKEWARM WATER AND LAY IT DOWN TO DRY OR DAB IT DRY WITH A LINT-FREE CLOTH OR TOWEL.

STORAGE - SAFELY STORE THE RING AT A DRY AND DARK PLACE. USE A TOY BAG TO PROTECT THE TOY FROM DUST AND SCRATCHES.


THIS PRODUCT IS SOLD AS A NOVELTY PRODUCT ONLY. ALL RIGHTS RESERVED. TO AVOID INJURY OR AGGRAVATION OF PRE-EXISTING CONDITIONS THIS PRODUCT SHOULD NOT BE USED ON BRUISED, SWOLLEN OR IRRITATED AREAS. ONLY USE THE PRODUCT AS INSTRUCTED. NO MEDICAL CLAIMS ARE WARRANTED OR IMPLIED BY THE USE OF THIS PRODUCT. ITS USE IS AT YOUR OWN RISK. DO NOT ATTEMPT TO WARM THIS PRODUCT IN A MICROWAVE OR CONVENTIONAL OVEN. WASH BEFORE AND AFTER USE. WITH A MILD SOAP AND WARM WATER. ALLOW TO DRY COMPLETELY BEFORE STORING SEPARATELY FROM OTHER TOYS IN A COOL, DRY PLACE. STORE AT ROOM TEMPERATURE. WE RECOMMEND USING A WATER-BASED LUBRICANT WITH YOUR PRODUCT. PLEASE DO NOT USE PERFUMED OR ALCOHOL-BASED LUBE GELS OR MASSAGE OILS TO AVOID DAMAGE. WE DO NOT RECOMMEND SILICONE-BASED LUBRICANTS OR GELS.

HOW TO USE | EQUIPMENT



1. LUBRICATE FIRST



2. POSSIBLE POSITIONS



SATURN | VIBRATING COCK & BALL RING





PRODUCT NUMBER / HUE001

EQUIPMENT SPECIFICATIONS

DIMENSIONS / 85*95*22 MM | 3.3*3.7*0.9 INCH
INNER DIAMETER RING / 47 MM | 1.9 INCH
MASS / 76 G | 2.65 OZ
SETTINGS / 3 VIBRATION SPEEDS, 7 PATTERNS
WATERPROOF / IPX7
MATERIALS / ABS, SILICONE

POWER / LI-ION, 180 MAH, 3.7V
MAX. CHARGING CURRENT / 350 MA
CHARGING VOLTAGE / 5.0 V
CHARGING TIME / APPROX. 50 MINUTES
OPERATING TIME / APPROX. 5.0 HOURS
STANDBY TIME / UP TO 6 MONTHS
MAX. NOISE LEVEL / <53 DB



 HOLD TO TURN THE COCK RING ON
 (PRESS TO CHANGE MODE)