



travel mode.

Your vibe will arrive in travel mode to ensure it won't turn on during transit. This will prevent the vibe from turning on or charging.

To turn off travel mode, hold down the power button for three seconds until you feel two quick pulses then travel mode will be deactivated. To turn on travel mode, hold the power button down again until you feel those same two quick pulses then travel mode will be activated.

Your vibe should ship with a partial charge though it may have been depleted over time. Before first use, charge your vibe for a full two hours.

charging.

For the vibe to charge, make sure the charging plug is fully inserted into the vibe's port. The light will turn on when your vibe is charging and it will turn off when complete. We recommend charging via a usb adapter (1A minimum) plugged in to a wall outlet. If the outlet that you try does not light up the vibe button, try using a different outlet.

Charging time: To reach a full charge will take between 1.5-2 hours.

Runtime: At highest speed: 1-1.5 hours At lowest speed: 2-2.5 hours.

Our vibe is powered by a rechargeable lithium-ion battery. The vibe battery (like all rechargeable batteries) becomes less effective with usage. If used weekly, we recommend replacing every year. If used more frequently, we recommend replacing sooner. To preserve the lifespan of your battery, charge fully after each use.

Warranty: our vibrators and devices have a one-year limited warranty. It is available [here](#).

Email orders@getmaude.com if you have any further questions or concerns.



using vibe.

1
To make things simple, there's a single button that controls the on/off and the vibration.

2
Press the button once to turn it on and the LED light will go on—this is the low setting.

3
Press again to get to the medium setting, a third time to get to the highest vibration, and again to cycle back through to the lowest setting.

4
To turn off the vibe, press and hold the button down for longer than one second. The LED light will go out when it's off (even the vibe needs its rest).

care.

cleaning & storage

Clean your vibe before and after every use with a mild, unscented hand or dish soap and water or [any toy cleaner](#).

Store in your maude pouch or separately from other toys—sex toys of different materials can damage each other if left in contact.

Keep away from extreme cold or heat.

lubricant usage

We recommend using the vibe with our organic lubricant or any other water-based lubricant of your choice.

Avoid use with silicone or oil-based lubricants as it will degrade the silicone.

water contact

The vibe is water-resistant and can be used in the shower and bath. The vibe should not be fully submerged.

