



meet spot.

Our first hand-held, 5-speed vibrator curved for internal g-spot or p-spot stimulation.

getting started.

travel mode

Spot will arrive in travel mode to ensure it won't turn on during transit. This will prevent the device from turning on or charging.

To turn off travel mode, hold down the power button for three seconds until you feel two quick pulses, then travel mode will be deactivated. To turn on travel mode, hold the power button down again until you feel those same two quick pulses, then travel mode will be activated.

Spot should ship with a partial charge though it may have been depleted over time. Before first use, charge your device for a full two hours.

charging

For spot to charge, make sure the charging plug is fully inserted into the device's port. The light will fade in and out when spot is charging and it will shine brightly when complete. We recommend charging via a usb adapter (1A minimum) plugged in to a wall outlet. If the outlet that you try does not light up the spot button, try using a different outlet.

Charging time: To reach a full charge will take between 1.5-2 hours.

Runtime: At highest speed: 1-1.5 hours. At lowest speed: 1.5-2.0 hours.

Spot is powered by a rechargeable lithium-ion battery. The device's battery (like all rechargeable batteries) becomes less effective with usage. If used weekly, we recommend replacing every year. If used more frequently, we recommend replacing sooner. To preserve the lifespan of your battery, charge fully after each use.

Warranty: our vibrators and devices have a one-year limited warranty that can be [viewed here](#). Scan the unique QR code that comes on your device's packaging to activate your warranty.

Email orders@getmaude.com if you have any further questions or concerns.



using spot.

1
To make things simple, there's a single button to controls your device's on/off function and five-speed vibration setting.

2
Press the button once to turn it on and the LED light will go on—this is the lowest setting.

3
Press again to get to the next setting and continue pressing to cycle up to the fifth and highest vibration. Press again to cycle back through to the lowest setting. The light will increase in brightness with each vibration level.

4
To turn off spot, press and hold the button down for longer than one second. The LED light will go out when it's off. When the device needs to be charged, its battery light will blink.

caring for spot.

cleaning & storage

Clean spot before and after every use with a mild, unscented hand or dish soap and water or any toy cleaner. Store in your maude pouch or separately from other toys—sex toys of different materials can damage each other if left in contact. Keep away from extreme cold or heat.

lubricant usage

We recommend using spot with our [organic lubricant](#) or any other water-based lubricant of your choice. Avoid use with silicone or oil-based lubricants as it will degrade your device over time.

water contact

Spot is water-resistant and can be used in the shower and bath. Your device should not be fully submerged.

