

# NEXUS<sup>®</sup> ACE

- 6 Vibration settings
- Rechargeable, waterproof plug
- Rechargeable, waterproof remote control



Ace is a luxury butt plug for those that want more from their pleasure products. Made from silky soft silicone, it's shaped for comfort with ridges on the shaft for extra stimulation. Six functions of vibration, pulsation and escalation can be controlled easily using the slim line remote control by the user or a partner. Comes with a convenient usb magnetic charger.

## Contents inside the box

- Nexus ace rechargeable vibrating butt plug
- Magnetic charge pad
- USB lead
- Remote control
- Instruction manual



## **Charging**

ACE is fully rechargeable via a USB lead which plugs directly into your computer or laptop. Located on the base of the toy there are two magnetic contacts where you attach the magnetic charge pad. Before charging, make sure that the magnetic contacts are clean.

- 1. Locate the USB lead and charger pad**
- 2. Insert the charger into a USB port on a computer or a USB plug**
- 3. Attach the charge pad on to the magnetic contacts located on the toy**
- 4. When the toy is charging the light will be red**
- 5. When Nexus ACE is fully charged, the light will turn to green**

Standard charging time is 75 minutes. This will give you approx 90 minutes of pleasure.

## **Remote Control**

The remote control uses a Li-polymer 3.7V rechargeable battery, 80mAh.

## **Turning On & Functions**

We recommend that you explore all the settings of your Nexus ACE before using it for the first time, so that your experience is optimised from the start.

You can enjoy three speeds of vibration, pulsation slow, pulsation fast and escalation.

## **Using the controls on Nexus ACE**

The On/Off and Function button is located on the base of the butt plug.

Simply press once to turn on. Continue to press the button to scroll through all the modes.

To turn off, simply hold down the On/Off button for a few seconds until all motion stops and the light goes dark.

## **Using the remote control**

You will need to turn the toy on using the button located on the base of the butt plug.

Simply press the button to scroll through the vibrating functions.

To turn off simply hold the button down for 2 seconds.

The remote control can be used up to 15 metres away.

## Cleaning, Storage & Safety

To prolong the life of your Nexus ACE we recommend that you follow the steps below:

Clean thoroughly before and after use. Simply spray with Nexus Wash antibacterial cleaner and wipe with a cloth. Alternatively you can wash with warm water and soap. Never use cleaners which contain alcohol or acetone.

Never use a silicone based lubricant as this will react with the silicone of your Nexus ACE and alter the feel of the toy. We recommend that you use a thick, high quality water based lubricant such as Nexus Slide.

Carefully storing your toy in a cool, dark place will prevent potential damage from dust and sunlight. Always store separately from other toys.

## Tips for Use

- 1. Empty your bowels and clean the area in preparation using an anal douche. You can buy a Nexus Douche from [nexusrange.com](http://nexusrange.com) or something similar from a pharmacy.**
- 2. In order to achieve maximum enjoyment from your toy, the most important thing to do is relax! As the anus does not produce sufficient natural lubricant for comfortable insertion, it is essential to ensure that a liberal amount of water-based lubricant such as Nexus Slide is used (DO NOT USE A SILICONE- BASED LUBRICANT). Apply your chosen lubricant directly to the tip and gently massage lubricant into the intended area of use. This process is important as it aids relaxation and promotes blood flow, thus increasing sensitivity.**
- 3. Slowly insert ACE. Remember that the sphincter muscle will not allow things to pass through the anus unless you relax and take it slowly.**
- 4. Once ACE is comfortably inserted you may wish to try vibration.**
- 5. Once you feel ready, press the button located on the underside of the base and scroll through the six stimulating vibration settings until you find the one most pleasurable for you.**

## Disposal information

Please note that disposal of old electronic waste must follow certain applicable regulations in the EU (and in other countries which have their own waste collection systems). Nexus Revo Stealth must not be treated the same as common household waste, instead it should be taken to your nearest collection point where electronic waste can be appropriately recycled. Contact your local authority for more information on your local collection points and applicable regulations.

## Disclaimer


Users of Nexus ACE use it at their own risk; neither the manufacturer nor the retailer assumes any responsibility or liability for the use this product. No medical claims are warranted or implied by use of this product.

**Model may be changed for improvements without any notice.**


If you experience a fault with your Nexus ACE, or would like further information please contact [info@nexusrange.com](mailto:info@nexusrange.com) or write to us at:

# NEXUS<sup>®</sup>

30b Spice Quay  
Shad Thames  
London, SE1 2YG



[www.nexusrange.com](http://www.nexusrange.com)



(C) Libertybelle Marketing Ltd. All rights reserved.  
Designed and developed by Libertybelle Marketing Ltd.