OTOUCH MASTURBATOR NINJA



User manual

CONTROL

GRAN

1) Hold down the top button with the M symbol for 3 seconds to turn it on. The masturbator will start the first vibration mode and the blue LED will light up.

2) Further short presses of this button change the individual vibration and pulsation rhythms.

3) Hold down the bottom button with the thermometer symbol to switch on the heating function to 35 °C, which is indicated by a flashing red LED.

4) Pressing this button briefly will turn on the red LED and start heating to 45 °C.

5) The heating and vibration functions can be triggered independently of each other.

6) Both functions must then be switched off with their own button by long pressing and holding the respective button for 3 seconds.

MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The masturbator is **water resistant**, so maintenance is very easy. The masturbator can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The masturbator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a masturbator and USB cable for charging.

Trinet Corp., s.r.o.

Potřebujete poradit?

Napište nám na flagranti@flagranti.cz nebo zavolejte na tel.: +420 774 082 678

Provozní 5560/1b 722 00 Ostrava – Třebovice, Czech Republic