

OTOUCH MASTURBATOR INSCUP 2 LUXURY

User manual



CONTROL

- 1) Remove the bottom magnet on the bottom of the masturbator where you will find the charging connector and power button. Hold it for 3 seconds to turn it on. The masturbator will welcome you vibrating and lighting up the hidden buttons on its body and the battery indicator.
- 2) Short presses of the bottom button with the wave symbol will start and change the individual vibration and pulsation rhythms.
- 3) To pause the vibration, hold this button for 2 seconds.
- 4) Short presses of the middle button with the oval symbol start and change the modes of imitation of muscle contractions.
- 5) To pause the function, hold this button for 2 seconds.
- 6) Short press the top button with the thermometer symbol to activate the heating function. The button LED will flash.
- 7) Press the button again briefly to switch off the heating function.
- 8) To turn the masturbator off, hold the power button for 3 seconds.

MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent. You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The masturbator is **water resistant**, so maintenance is very easy. The masturbator can be splashed with water, but you **MUST NOT immerse it in water!** Waterproof means that you could completely submerge the product in water and enjoy water play. Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The masturbator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a masturbator and USB cable for charging.