

OTOUCH MASTURBATOR DECOR 2

User manual



CONTROL

- 1) Before use, plug the stand's USB cable into the appropriate slot. The UV LEDs will light up and the cleaning process will begin.
- 2) At the same time, the masturbator will start to heat up pleasantly. After about 5 minutes it is ready for use.

MAINTENANCE

After each use, rinse the masturbator with lukewarm water and soapy detergent. Allow to dry completely and can be put back in the rack for UV cleaning. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The masturbator is **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The masturbator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use. Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find, a stand for the masturbator, a masturbator and a USB cable for charging.