

User manual

Vibrator

Open the battery compartment at the bottom of the vibrator and insert two AA batteries. Close the battery compartment. Press the power button at the bottom to turn on the vibrations. Press the button again to go to the next setting. There are 3 vibration speeds and 7 vibration patterns in total. The vibrator can be combined with all types of lubricant. Rinse the vibrator with lukewarm water after use. Apply toy cleaner and rinse the vibrator again with lukewarm water. Repeat this step if necessary. Lay the vibrator down to dry or dry it off with a clean cloth or towel.

Butt plug

Apply water-based anal lubricant to the butt plug and carefully insert it anally. Make sure the flat base of the plug remains outside the body at all times. Rinse the butt plug with lukewarm water after use. Apply toy cleaner and rinse the butt plug again with lukewarm water. Repeat this step if necessary. Lay the butt plug down to dry or dab it dry with a lint-free cloth or towel. The butt plug is made of silicone. Therefore the butt plug can only be used in combination with water-based lubricant. Other lubricants can negatively affect the material, allowing bacteria to grow and making it impossible to hygienically clean the toy.

Mask

Place the mask in front of the eyes and put the elastic strap around the head.

Paddle/flogger

Use the paddle/flogger to caress or punish your partner.

Handcuffs/ankle cuffs

Put the cuffs around the wrists/ankles and fasten the buckles. The chain connecting the cuffs can be attached/removed if desired.

Collar with leash

Put the collar around the neck and use the Velcro strap to fasten it.

Disclaimer

This product is sold as a novelty product only. All rights reserved. To avoid injury or aggravation of pre-existing conditions this product should not be used on bruised, swollen or inflamed areas. Only use the product as instructed. No medical claims are warranted or implied by the use of this product, its use is at your own risk.