

# PRETTY LOVE SHELL VIBRATOR



## User manual

### CONTROL

- 1) Turn on the vibrator by briefly pressing the "power" button on the bottom of the vibrator. The LED will light up and the vibrator will switch to standby mode.
- 2) Briefly press the button with the "wave" symbol to switch between the individual vibration programs.
- 3) For use with the remote control, press the "power" button on the remote control to turn it on.
- 4) Briefly press the button with the "wave" symbol on the remote control to switch between the individual vibration programs.
- 5) Briefly press one of the two "power" buttons to switch the device to standby mode.
- 6) Briefly press both of these buttons if you want the Shell to be completely turned off..

### MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The product is **not waterproof or water resistant!**

### LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The product is powered by a AAA battery. For longer battery life, we recommend using alkaline or rechargeable batteries.

The remote control is powered by two AAA batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a vibrator and a remote control.