

ONDA

FIRST STEPS


1. Only insert or remove Onda when it is fully turned off and the G-spot Massager is completely retracted.
2. Charge your Onda for at least 1 hour before the first use.
3. Wash with mild soap and water or your favorite silicone-safe cleaner.
4. Apply a water-based lubricant or personal moisturizer to the G-spot Massager. Do not use lubricants that contain silicone or oils—this could cause damage to the product and reduce the lifespan of your device.
5. Insert Onda into the vaginal opening with the G-spot Massager facing the front of the body. Explore to find the right position of the massager over the G-spot, it can be different for every person.
6. Press and hold the power button to turn on.
7. Customize your desired stimulation using the stroke, speed, and boost buttons. Take your time to adjust, explore, and enjoy.
8. To end your session, firmly press and hold the power button to turn Onda off before removing your device.
9. Thoroughly clean and dry your device before storing

FINDING YOUR FIT

FINDING YOUR PERFECT FIT


Before first time use, we recommend familiarizing yourself with your own anatomy to understand how Onda will fit comfortably against your body.

It may take a few sessions to explore and find the position and intensity you prefer. Take your time and enjoy the self-discovery!



GET TO KNOW YOUR G-SPOT

It is theorized that the G-spot is actually the deeper portion of clitoral tissue. In most people the G-spot is about 1–3 inches (2–8cm) inside the entrance on the front wall of the vagina. The tissue tends to be slightly firmer and more rigid than the surrounding tissue. Onda is designed to press and stroke the full length of the G-spot.




USING YOUR ONDA

- We recommend testing out Onda's functions before inserting into the vagina so you can see all of the options and settings.
- Only insert or remove Onda when it is fully turned off and the G-spot Massager is completely retracted.
- Add a small amount of water-based lubricant or personal moisturizer to the G-spot Massager for smooth insertion and use.
- Insert Onda into the vaginal opening with the G-spot Massager facing the front of the body.
- Once inserted, turn Onda on and explore to find a position that presses against the G-spot. Adjust the angle of the massager to press and stroke over the inside front wall of the vaginal canal.
- Each of Onda's functions can be controlled independently, so try out different combinations of stimulation to find your favorite settings.
- Always turn Onda off completely before removing from the vagina. Simply press and hold the power button, then once it is fully off, remove.

CHARGING ONDA

- We recommend testing out Onda's functions before inserting into the vagina so you can see all of the options and settings.
- Only insert or remove Onda when it is fully turned off and the G-spot Massager is completely retracted.
- Add a small amount of water-based lubricant or personal moisturizer to the G-spot Massager for smooth insertion and use.
- Insert Onda into the vaginal opening with the G-spot Massager facing the front of the body.
- Once inserted, turn Onda on and explore to find a position that presses against the G-spot. Adjust the angle of the massager to press and stroke over the inside front wall of the vaginal canal.
- Each of Onda's functions can be controlled independently, so try out different combinations of stimulation to find your favorite settings.

- Always turn Onda off completely before removing from the vagina. Simply press and hold the power button, then once it is fully off, remove.



25% charged



50% charged



75% charged



100% charged

TIPS AND TRICKS

DO NOT INSERT OR REMOVE ONDA WHILE IT IS POWERED ON.

Make sure Onda is completely powered off and the G-spot massager is fully retracted before insertion and removal.

USE LUBE

A good, water-based lube can make sexual exploration smoother, more fun, and can enhance the sensations (silicone or oil-based lube can damage the material).

GET TO KNOW YOUR BODY FIRST.

Find your G-spot by inserting a finger about 1-3 inches into your vagina and explore by rubbing or stroking over the front wall, using a come hither motion. When you feel a firmer, slightly rippled texture, you've found your G-spot.

AROUSAL AND RELAXATION ARE KEY.

Warm yourself up and get excited before inserting Onda. Staying relaxed during insertion and removal, and using lube will help you find the best fit and sensations.